

Grid-Hybrid Inverter SPH 10000TL-HU-US(B)



Download
Manual



Growatt New Energy

Shenzhen Growatt New Energy Co., Ltd
4-13/F, Building A, Sino-German (Europe) Industrial Park,
Hangcheng Ave, Bao'an District, Shenzhen, China

T +86 0755 2747 1942
E service@ginverter.com
W www.ginverter.com

GR-UM-137-A-01



044.SK0013702

Version:1.2

Table Of Contents

1 Information on this Manual	1
1.1 Overview	1
1.2 Intended Audience	1
1.3 Safety Instructions	1
2 Production Introduction	3
2.1 Product Overview	3
2.2 Function Port Definition	4
2.3 Product Size	5
2.4 Product Features	5
2.5 Basic System Architecture	6
3 Installation	7
3.1 Parts List	7
3.2 Mounting Instructions	7
3.3 Battery Connection	9
3.4 Grid Connection and Backup Load Connection	10
3.5 PV Connection	11
3.6 Meter or CT Connection	13
3.7 Earth Connection(Mandatory)	14
3.8 Dip Switch Status	14
3.9 Fan Replacement	15
3.10 Wiring System for Inverter	16
3.11 Split Phase(120/240Vac) Parallel Connection	17
3.12 2Pcs Parallel Connection for 120/208 Three Phase	19
3.13 3Pcs Parallel Connection for 120/208 Three Phase	21
3.14 6Pcs Parallel Connection for 120/208 Three Phase	23
4 Operations on The ShineTools APP	25
4.1 Overview	25
4.2 APP Download	25
4.3 Login	25
4.4 Direct WiFi/Bluetooth Commissioning Tool	26
4.5 Commissioning of SPH 10000TL-HU-US(B)	27
4.6 Parameter Setting (Specific to the App display setting items)	28
5 Operations on The ShinePhone APP	29
5.1 Overview	29
5.2 APP Download	30
5.3 APP Introduction	30

6 Operation	38
6.1 Power ON/OFF	38
6.2 Operation and Display Panel	38
7 Main Screen	39
7.1 Touchscreen Operation Flow Chart	39
7.2 Main Screen	40
7.3 Setting Menu	43
7.4 Basic Settings	44
7.5 Battery Settings	44
7.6 Operating Modes	46
7.7 Grid Settings	50
7.8 Generator Settings	52
7.9 Advanced Functions	53
7.10 Device Info.	54
8 Fault Information and Processing	55
9 Data Sheet	59
10 Appendix I	61
11 Appendix II	61
12 Appendix III	62
13 Appendix IV	62
14 Appendix V	62
15 Appendix VI	63

1 Information on this Manual

1.1 Overview

This manual is intended to introduce the SPH 10000TL-HU-US(B) Inverters manufactured by Shenzhen Growatt New Energy Co.,Ltd. (hereinafter referred to as Growatt) in terms of the installation, operation, commissioning, maintenance and troubleshooting. Please read this manual carefully before using the product, and keep it in a place that is easily accessible to installation, operation and maintenance personnel. The content is continually reviewed and amended as necessary. Growatt reserves the right to make changes to the material at any time and without notice.

1.2 Intended Audience

Only qualified electrical technicians are allowed to install SPH 10000TL-HU-US(B) Inverters. Reading through this manual and observing all the precautions, qualified electrical technicians will be able to properly install, troubleshoot and configure the SPH 10000TL-HU-US(B) Inverters. If any questions arise during installation, you can visit www.growatt.com and leave a message.

1.3 Safety Instructions

1. Please read this manual carefully before installation. Damages caused by failure to follow the instructions in the manual are beyond the warranty scope.
2. Only qualified and trained electrical technicians are allowed to perform operations on the Storage Inverter.
3. During installation, please do not touch other parts inside the equipment except wiring terminals.
4. Ensure that all electrical connections comply with local electrical standards.
5. For maintenance, please contact designated local installation and maintenance personnel.
6. Before operating the inverter in the on-grid mode, ensure that you have obtained any permission needed from the local electricity grid network operator.




- a. Electrical installation, repairs and conversions may only be carried out by electrically qualified persons
- b. DO NOT connect the grid to the Load Output Breaker.
- c. DO NOT reverse the polarity of batteries. Damage will occur.
- d. The components in the inverter are live. Touching live components can result in serious injury or death.
- e. Non professional, please do not open the inverter.
- f. Beware of high PV voltage. Please turn-off the DC switch of PV Panel output before and during the installation to avoid electric shock.
- g. Beware of high grid voltage. Please turn-off the AC switch at the grid connection before and during the installation to avoid electric shock.
- h. Beware of large current of the battery output. Please turn-off the battery module before and during the installation to avoid electric shock.

	a. Make all electrical connections (e.g. conductor termination, fuses, PE. connection, etc.) in accordance with prevailing regulations. When working with the inverter powered on, adhere to all prevailing safety regulations to minimize risk of accidents. b. Systems with inverters typically require additional control (e.g. switches, disconnects) or protective devices (e.g. fusing circuit breakers) depending upon the prevailing safety rules. c. ALL terminals/breakers including battery, MPPT, and AC breaker inputs should only have one conductor connecting to them. d. Anytime the inverter has been disconnected from the power net work,use extreme caution as some components can retain charge sufficient to create a shock hazard; to minimize occurrence of such conditions,comply with all corresponding safety symbols and markings present on the unit and in this manual. e. Ensure all covers and doors are closed and secure during operation. All operations regarding transport, installation and start-up, including maintenance must be operated by qualified, trained personnel and in compliance with all prevailing codes and regulations. f. Although designed to meet all safety requirements, some parts and surfaces of Inverter are still hot during operation. To reduce the risk of injury, do not touch the heat sink at the back of the PV-Inverter or nearby surfaces while Inverter is operating.
	a. Please carefully read this manual before any work is carried out on this inverter, the installation,please keep this manual carefully stored and easy to access at any time. b. The qualified personnel should have had training in the installation and commissioning of the electrical system as well as dealing with hazards, also they should have the knowledge of the manual and other related documents. As the installer or operator they are required to be familiar with local regulations and directives.


2 Production Introduction

2.1 Product Overview



- | | |
|-------------------------|---|
| 1: LCD Display | 9: Neutral /Ground Bus Bar |
| 2: Inverter Indicators | 10: DRMS Port |
| 3: Power ON/OFF button | 11: Upgrading Port(USB) |
| 4: PV Switch | 12: BMS Port |
| 5: Function Port | 13: Upper Computer Port |
| 6: 250A Battery Breaker | 14: Parallel-B Port |
| 7: Battery Input | 15: Parallel-A Port |
| 8: PV Input | 16: AC Breaker(Grid 100A/Gen 63A/Load 100A) |

2.2 Function Port Definition



TEMP (1,2): Battery temperature sensor for lead acid battery.

CT-L1 (3,4): Current transformer (CT1) for "Zero Export Limit" mode clamps on L1 when in split phase system.

CT-L2 (5,6): Current transformer (CT2) for "Zero Export Limit" mode clamps on L2 when in split phase system.

G-start (7,8): Generator start signal should be connected to the CON board CN9 terminal 7/8 position, G-start nominal open circuit. If the user wants to start the generator, G-start nominally closes the port.

G-valve (9,10): Reserved.





Fig 1.1 GS (diesel generator startup signal)



RSD (CN17): Provide 12Vdc output when inverter is on.

ATS (CN16): 240V output port when inverter is on.

BMS (CN4): RS 485 (1B,2A), CAN (4H,5L) port for battery communication.

Parallel A (CN8): Parallel communication port 1 (CAN interface).

Parallel B (CN7): Parallel communication port 2 (CAN interface).

Meter (CN6): For energy meter communication. Some hardware versions don't have this port.

LAN(CN2B): LAN port.

USB(CN22): USB port.

Upper Computer (CN5): Upper Computer Port

2.3 Product Size





Fig 1.2 Inverter Size

2.4 Product Features

- Supports Split phase 120/240Vac, Three-phase 120/208Vac system.
- Self-consumption and export to the grid.
- Configurable battery charging current/voltage based by touch screen setting.
- Configurable AC/Solar/Generator Charger priority by touch screen setting.
- Compatible with grid voltage or generator power.
- AC power loss restart.
- Time of use function.
- Smart battery charger design for optimized battery performance.
- Supporting WiFi/4G/Bluetooth monitoring and build-in 3 strings of MPPT.
- Smart settable three stages MPPT charging for optimized battery performance.
- Overload/Over temperature/Short circuit protection.
- Programmable supply priority for battery or grid.
- Programmable multiple operation modes: On Grid Mode, Self-consumption Mode, Zero Export Limit.

2.5 Basic System Architecture

The following illustration shows basic application of this inverter.

It also includes following devices to have a complete running system.


-Generator or Utility

-PV modules

-Battery

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as refrigerator and air conditioner.



3 Installation

3.1 Parts List

Check the equipment before installation. Please make sure nothing is damaged in the package.

You should have received the items in the following package:

Part List			A	B	C	D
Item	Description	Qty				
A	Hybrid inverter	1				
B	User manual	1				
C	Wall Bracket	2				
D	Stainless steel anti-collision bolt	4				
E	Battery temperature sensor	1				
F	Tubular terminal:6AWG,10AWG	9+12				
G	Rod antenna	2				
H	Fuse	1				
I	Parallel line	2				
J	Mounting template	1				
K	Sensor Clamp	2				
L	RSD Emergency Stop Switch	1				

3.2 Mounting Instructions

Installation Precaution

This Hybrid inverter is designed for outdoor use(IP65), Please make sure the installation site meets below conditions:

- Not in direct sunlight.
- Not in areas where highly flammable materials are stored.
- Not in potential explosive areas.
- Not in the cool air directly.
- Not near the television Antenna or antenna cable.
- Not higher than altitude of about 2000 meters above sea level.
- Not in environment of precipitation or humidity(>95%).

Considering the following before selecting where to install:

- Please select a vertical wall with load-bearing capacity for installation, suitable for installation on concrete or other non-flammable surfaces, installation is shown below.
- Install this inverter at eye level in order to allow touch screen display to be read at all times.

- The ambient temperature should be between -25~60°C to ensure optimal operation.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and have enough space for removing wires.



-For proper air circulation to dissipate heat, allow a clearance of approx.50cm to the side and approx.50cm above and below the unit. And 1000mm to the front.


Mounting the inverter

Remember that this inverter is heavy! Caution when lifting out from the package.


- 1.Please Make sure that the thickness of the wall for inverter installation is more than 70mm.
- 2.Please Place the template horizontally on the wall and confirm the level by level.



- 3.Please mark the holes in the 4 mounting holes of hole pattern.
- 4.Drill a hole with a depth of 65mm at the mark with a drill of 10mm.



- 5.Please knock the expansion screw rubber sleeve into the hole on the wall, and then screw on the Expansion screw.
- 6.Please hang the inverter on the expansion screws, and then tighten the expansion screws.



3.3 Battery Connection

For safe operation and compliance, a separate DC over-current protector or disconnect device is required between the battery and the inverter. In some applications, switching devices may not be required but over-current protectors are still required.

Model	Wire Size
SPH 10000TL-HU-US(B)	2/0AWG or 4/0AWG




WARNING


All wiring must be performed by a professional person. Connecting the battery with a suitable cable is important for safe and efficient operation of the system. To reduce the risk of injury, refer to chart for recommended cables.

Please follow below steps to implement battery connection:

- 1.Please choose a suitable battery cable with correct connector which fits into the battery terminals.
- 2.Use a philips screwdriver to unscrew the bolts and fit the battery connectors in, then fasten the bolt by the screwdriver, make sure the bolts are tightened in clockwise direction.
- 3.Make sure polarity at both the battery and inverter is correctly connected.



Temperature sensor connection for lead-acid battery



3.4 Grid Connection and Backup Load Connection

Before connecting to grid, please install a separate AC breaker between inverter and grid. Also, it is recommended to install an AC breaker between backup load and inverter. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current. The recommended of AC breaker is 80A for 10kw.

There are three terminal blocks with "Grid" "Load" and "GEN" markings. Please do not disconnect input and output connectors.





WARNING All wiring must be performed by a qualified personnel. It is very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable as below.

Model	Wire Size
SPH 10000TL-HU-US(B)	6 AWG

Please follow below steps to implement AC input/output connection:

1. Before making Grid, load and Gen port connection, be sure to turn off AC breaker first.
2. Remove insulation sleeve 10 mm for positive and negative conductors.
3. Use crimping pliers to press the 6AWG cable onto the attached tubular terminal to form a square.
4. Install the AC conduit to the AC grid output opening (Grid, Gen, Load). Use appropriate conduit fittings and bond where necessary.
5. Terminate the AC conductors to the appropriate terminal.

L2	L1	L2	L1	L2	L1
Grid		GEN		Load	





NOTICE Be sure that AC power source is disconnected before attempting to wire it to the unit.

Appliances such as air conditioner are required at least 2-3 minutes to restart because it is required to have enough time to balance refrigerant gas inside of circuit. If a power shortage occurs and recovers in short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it is equipped with time-delay function before installation. Otherwise, this inverter will trigger overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

3.5 PV Connection

Before connecting to PV modules, please install a separate DC circuit breaker between inverter and PV modules. It is very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Wire Size
SPH 10000TL-HU-US(B)	10AWG



WARNING To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using PV modules, please be sure NO grounding. It is requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

3.5.1 PV Module Selection

When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules should not exceed max PV array open circuit voltage of inverter.
2. Open circuit Voltage (Voc) of PV modules should be higher than min start voltage.

Inverter Model	SPH 10000TL-HU-US(B)
PV Input Voltage	370V(130V-525V)
PV Array MPPT Voltage Range	150V-450V
No. of MPPT Trackers	3
No. of Strings per MPPT Tracker	2+2+2

3.5.2 PV Module Wire Connection


Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10 mm for positive and negative conductors.
2. Use crimping pliers to press the 10AWG cable onto the attached tubular terminal to form a square.
3. Check correct polarity of wire connection from PV modules and PV input connectors. Then, connect positive pole (+) of connection wire to positive pole (+) of PV input connector. Connect negative pole (-) of connection wire to negative pole (-) of PV input connector. Close the switch and make sure the wires are tightly fixed.
4. Parallel strings per MPPT must be the same Voltage.
 - a. PV1 A/B must be the same voltage if using both strings.
 - b. Panels on the same MPPT CAN face different directions.
5. Terminate the PV strings to the appropriate terminal.



NOTICE Make sure the wire is tight and secure.

1	2	3	4	5	6	7	8	9	10	11	12
PV1+	PV2+	PV3+	PV1-	PV2-	PV3-						




3.5.3 Rapid Shutdown

The inverter includes a rapid shutdown system that complies with 2017 and 2020 NEC 690.12 requirements.

In case of emergency, press the rapid shutdown button that cut off the RSD power supply, thus stopping the inverter AC output, and the PV conductors voltage will be reduced to less than 30V within 30 seconds


1. Mounting the RSD initiation switch

- Using a Philips head screwdriver, unscrew the 4 plastic screws of the assembled RSD initiation switch to open the enclosure.
- Use the base of the enclosure to mark 4 holes on the wall and drill the holes out. Insert the wall anchors into the holes.
- Align the holes of the RSD initiation switch base with the holes in the wall. Using a Philips screwdriver, screw the self tapping screws through the enclosure base into the wall anchors.



2. Wiring the RSD initiation switch


- Install RSD switch wire to the COM input, use appropriate conduit fittings and bond where necessary. Run the signal wire.
- Connect the wire to the RSD switch as shown.
- Reinstall the RSD initiation switch cover and tighten the plastic screws to secure.
- Remove the 3-pin connector from terminal CN17 and remove the jumper across the pins.
- Insert the wire in the 3-pin conductor's positions 1 and 3, as shown.
- Replace the connector in the terminal CN17 and replace the inverter wire box cover.




3.6 Meter or CT Connection

Meter Connection

Cable	Meter	Inverter	Type	Conductor cross-sectional area range
AC wire-L1	ΦL1	n/a	solid or stranded wire but not fine stranded wire	6AWG
AC wire-L2	ΦL2			
AC wire-N	N			
Ground	PE symbol	n/a	n/a	n/a
CT-ΦL1	L1 CT +/-			
CT-ΦL2	L2 CT +/-			
Communications cable	RS485 A+		Min. 3-wire shielded twisted pair	0.2-1 mm ² / 24-18 AWG
	RS485 B-			



CT Connection(How to set CT, please refer to 7.9)



3.7 Earth Connection(Mandatory)


Ground cable shall be connected to ground plate on grid side this prevents electric shock.

Model	Wire Size
SPH 10000TL-HU-US(B)	12AWG

If the original protective conductor fails. Please follow below steps to implement Ground cable connection:


Please follow below steps to implement Ground cable connection:

1. Remove insulation sleeve 10 mm for wire.
2. Loosen the screw, insert the ground wire and then tighten the screw. Please make sure that the ground cable is firmly connected to the ground bar.



3.8 Dip Switch Status

Working condition	Switch status
Connect to the collector(Default)	3/4→ON; 1/2:OFF 
Local upgrade	3/4→OFF; 1/2:ON 




3.9 Fan Replacement


Please check and clean the fans regularly. The recommended period is 6 months.

Please replace the fan following up the below diagram if there is problem with the fans. Turn off the system and wait for more than 5 minutes before disassembling the machine.


- a. Loosen the screws and remove them.



- b. Remove the fan fixing.




- c. Pull out the fan bracket completely, and use a soft brush to clean the fan or replace a damaged fan.



- d. Remove the fan and replace it.
- e. After the fan is installed, follow the steps just now to push back and assemble it back.

3.10 Wiring System for Inverter




The external circuit breakers on the backup load side, generator side, grid side and battery side are optional. The inverter already has these breakers internally. The specifications are given below.

Inverter Model	SPH 10000TL-HU-US(B)
PV Breakers(①)	600V/30A
Battery Breaker(②)	80V/250A
Generator breaker(③)	240V/63A
Load Breaker(④)	240V/63A
AC Breaker(⑤)	240V/100A
On-Grid Home Load Breaker(⑥)	240V/100A


3.11 Split Phase(120/240Vac) Parallel Connection

Three inverters in parallel:


Power Connection




Inverter NO.1




Inverter NO.2



Inverter NO.3



Communication Connection



Modbus SN: This feature is currently not being used.

The status of the toggle switch needs to be fully turned on.

CT1: Connect pins 3 and 4 of L1 (Inverter NO.1).


CT2: Connect pins 5 and 6 of L2 (Inverter NO.1).

Allow for 6 machines to be combined.


3.12 2Pcs Parallel Connection for 120/208 Three Phase

Two inverters in parallel:


Power Connection




Inverter NO.1



Inverter NO.2



Communication Connection



Modbus SN: This feature is currently not being used.

The status of the toggle switch needs to be fully turned on.

CT1: Connect pins 3 and 4 of L1 (Inverter NO.1).

CT2: Connect pins 5 and 6 of L2 (Inverter NO.1).


CT3: Connect pins 3 and 4 of L2' (Inverter NO.2).


This situation can only be set to phase A and B.

3.13 3Pcs Parallel Connection for 120/208 Three Phase

Three inverters in parallel:

Power Connection







Inverter NO.1




Inverter NO.2



Inverter NO.3



Communication Connection



Modbus SN: This feature is currently not being used.

The status of the toggle switch needs to be fully turned on.

CT1: Connect pins 3 and 4 of L1 (Inverter NO.1)


CT2: Connect pins 5 and 6 of L2 (Inverter NO.1)


CT3: Connect pins 3 and 4 of L1" (Inverter NO.3).

3.14 6Pcs Parallel Connection for 120/208 Three Phase

Three inverters in parallel:

Power Connection





Communication Connection



Modbus SN: This feature is currently not being used.

The status of the toggle switch needs to be fully turned on.

CT1: Connect pins 3 and 4 of L1 (Inverter NO.1).

CT2: Connect pins 5 and 6 of L2 (Inverter NO.1).

CT3: Connect pins 3 and 4 of L1" (Inverter NO.5).

4 Operations on The ShineTools APP

4.1 Overview

ShineTools is a smart APP that could realize the inverter system local commissioning function via the smart phone. It communicates with the inverter through internal Bluetooth or data logger to realize real-time status monitoring, alarm query, parameter configuration, intelligent diagnosis and other routine maintenance functions, is a convenient local configuration platform.

-Real-time status monitoring: Captures the real-time status of inverters and data loggers.

-Alarm query: There are easy-to-operate alarm function and flexible alarm display mechanism could help obtain fault location information quickly, and convenience for customers to take countermeasures timely, improve the efficiency of operation and maintenance.

-Parameter configuration: Simple and safe parameter configuration, and one-stop unified configuration can be realized through the data logger.

4.2 APP Download

Scan the QR code or search for "ShineTools" in Google Play or Apple Store to download and install the APP;



4.3 Login




Start the APP.

-Choose the end user or O&M account.

-Enter the account and password and log in. End user password is oss+current date (example April 16, 2024 is oss20240416)


-After login successfully, you can check the "Installation Manual".





4.4 Direct WiFi/Bluetooth Commissioning Tool



- Select the Direct WiFi/Bluetooth Channel.
- Select the corresponding model.
- Scan the device serial number barcode on the right side of the inverter to configure Bluetooth. You can also configure Bluetooth by manually entering the device serial number.
- Enter the Local Commissioning interface.



4.5 Commissioning of SPH 10000TL-HU-US(B)

Local Commissioning> Quick Setting> Network Type

- Select/fill network, enter the password, and select the server address.
- Choose the network configuration method-WiFi.
- Click to connect to the network.



5.2 APP Download

There are three ways to download the ShinePhone APP.

5.2.1 Scan the QR code



Scanning the QR code, then download the APP.

5.2.2 APP Store

Search for ShinePhone from one of the following app stores in the following list, download the installation package, and install the ShinePhone app by following the in instructions.

-Google Play (Android)

-App store (iOS)

5.2.3 Website

Log in to our monitoring website <https://server-us.growatt.com> to download.

After the app is installed, the ShinePhone icon is displayed on the home screen.



5.3 APP Introduction

5.3.1 Multiple Languages Supported

ShinePhone supports multiple languages. APP language automatically switches according to the user's mobile language.

5.3.2 Local Tool

You can choose to configure the local debugging tool by clicking the tool below the login interface. Use the debugging tool for real-time device control and for device monitoring.

5.3.3 Login to ShinePhone

Connecting to the inverter Collector to allow for real-time status monitoring, system mode management, performing routine maintenance, and commissioning. It's also the first step in remote network configuration.

- Open the ShinePhone app to register an account, log in to your account after registration is complete


-You can switch the App language through the upper right corner.

-Select country and religion.

-Enter username and password.

-Click "Remember Password" to save your password.



-Click to log in to the homepage.



5.3.4 Add power station and collector


-Create a power station after logging in to the homepage (Note: Items marked * are required. Please fill it out correctly.)

-You can add the collector to the corresponding power station by scanning the collector "SN" number (VCxxxxxxxx) on the right side of the inverter, or you can enter it manually.




5.3.5 Main interface display and power station list

- After successfully creating a power station and adding a collector, it will automatically jump to the APP main interface.
- Click "Plant" in the lower tab bar to jump to the plant list interface, and click the corresponding plant to view the generation, power and the other parameters of each inverter under each plant.




- Click "—" to modify the power station details (for example: power station name, photovoltaic components, etc.)



- Click "!" to quickly view the current working data of the inverter (Solar voltage/Battery voltage/Grid voltage/Grid frequency/Output voltage/Output frequency).
- Click the fault icon in the lower right corner to display the current machine fault information details.

5.3.6 Details and parameter settings in the power station

- If you need to add, view, delete the datalogger or add a plant, please click the "+" in the upper right corner.
- Note: If the datalogger needs to change the account monitoring, you need to delete the datalogger under the original account, then add the datalogger under the new account.





- Drag the screen down to see the energy trend graph. This interface can view the current power, SOC usage (only in lithium battery mode) and battery charge and discharge energy. You can also view the daily, monthly, and annual photovoltaic output/feed into the grid/load consumption/grid power withdrawal/self-consumption cumulative electricity.




-In the My device list at the bottom of the interface, you can view the status (signal strength, refresh time, etc.) of all collectors added to the power station.

-You can also enter the detailed parameter reading and control interface of the inverter according to the device serial number.




- This interface can display the real-time status of the data, and you can also view the detailed parameters of the inverter, solar energy, grid, battery, and load under the working status of the device, as well as the basic parameters of the device itself (For example: serial number, model, firmware version...).



- Energy trend graphs can also be found here. For more details, we can click on the icon in the upper right corner to view it.




-In the log at the bottom of the interface, you can view the device's historical fault records and fault details.



- Equipment control interface: Users can turn on and off the machine on the equipment control interface. Set the maximum charging current, maximum discharge current, inversion time, grid voltage upper limit, grid voltage Lower limit etc. The password is: growatt + current date.(Notice: Do not change parameters at will as this may cause your inverter to malfunction.)



Device editing page: Users can edit device aliases and delete devices.



6 Operation

6.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press On/Off button(located on the left side of the case) to turn on the unit. When one of the grid or PV is connected the screen will stil light up even if the battery is not connected, In this condition, the system can still work normally when switch on the ON/OFF button and select NO battery mode.


6.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators and a touch screen display, indicating the operating status and input/output power information.

LED Indicator			Messages
AC/INV	GREEN	Light	Powered by AC
		Twinkle	Powered by DC
CHARGE	GREEN	Light	Full battery
		Twinkle	Charging
FAULT	RED	Light	Error
		Twinkle	Warning

7 Main Screen

7.1 Touchscreen Operation Flow Chart



7.2 Main Screen



Icon	Description
	PV
	Battery: Battery Power Charge(negative) Discharge
	Inverter
	Generator
	Setting Menu
	Grid: Grid Power Export(negative) Import(positive)
	Load
	BMS communication error

1.The "Grid-on" in the above of the home screen indicates that the system is Normal operation. If it turns into "Fault": F17-F64 or Alarm: W01-W96",it means the inverter has communication errors or other errors, the error message will display the upper left corner of the home screen.F17-F64 faults and W01-W96 alarms, detailed information can be found in the exclamation mark in the upper right corner of the main screen.

2.At the top of the screen is the time.

3.System Setup Icon, press this set button, you can enter into the system setup screen which including Basic Settings, Operating Modes, Grid Settings, Generator Settings, Battery Settings and Advanced Functions.

4.The main screen showing the info including Solar, Grid, Load and Battery. Its also displaying the energy flow direction by arrow.

-PV power and Load power always keep positive.

-Grid power negative means sell to grid, positive means get from grid.

-Battery power negative means charge, positive means discharge.

5. When there is an abnormal BMS communication, a BMS alarm icon will appear in the bottom left corner of the screen. After this alarm occurs, the lithium battery automatically switches to lead-acid battery, but cannot be charged.

PV Detail Page

PV					
Power	618 W				
PV1-P	208 W	PV2-P	205 W	PV3-P	205 W
PV1-V	364.8 Vdc	PV2-V	361.1 Vdc	PV3-V	361.7 Vdc
PV1-I	0.5 Adc	PV2-I	0.5 Adc	PV3-I	0.5 Adc
Today	0.5 kWh	Total	260.8 kWh		

Solar Panel Generation.

Power,Voltage,Current for each MPPT.

Solar panel energy for Day and Total.

Grid Detail Page

Grid					
Import From Grid	35 W	50.03 Hz			
L1-V	118.8 Vac	L2-V	119.2 Vac		
CT1	12 W	CT2	23 W		
L1-P	12 W	L2-P	23 W		
Import From Grid	Today	0.1 kWh	Total	0.6 kWh	
Export To Grid	Today	38.9 kWh	Total	139.1 kWh	

Status(Import From Grid,Export From Grid,Stand-by), Power, Frequency.

L1-V&L2-V: Voltage for each phase.

CT1&CT2: External Current Sensor Power.

Grid Power L1&Grid Power L2:

Internal Current Sensor Power. Solar panel import from grid for Today and Total, Solar panel export to grid for Today and Total.

Battery Detail Page

Battery	
Battery Status	Discharge
SOC	100 %
Voltage	48.90 Vdc
Current	1.9 Adc
Power	94 W
Temperature	27.9 °C

The image on the left shows the display screen when using % to measure the remaining power of the battery and make settings.

Battery	
Battery Status	Discharge
Voltage	48.90 Vdc
Current	1.9 Adc
Power	94 W
Temperature	27.9 °C

The image on the left shows the display screen when using voltage to measure the remaining power of the battery and make settings.

LI-BMS	
Battery Status	Discharge
SOC	43 %
Voltage	52.7 Vdc
Current	5.2 Adc
Power	274 W
Temperature	28.4 °C

If you use Lithium Battery,you can enter 1-2 page.

LI-BMS	
Mean Voltage	52.8 Vdc
Total Current	1.5 Adc
Mean Temp	28.4 °C
Total SOC	43 %
Dump Energy	45 Ah

Inverter Detail Page

Inverter	
Power	28 W
L1-V	120.1 Vac
L1-I	0.7 Aac
L1-P	10 W
AC-Temp	34.9 °C

Inveretr Generation Power and Frequency. Voltage,Current,Power for each phase.

AC-Tem: Temperature of Heat-sink.

DC-Temp: Temperature of DC-DC module.

Generator Detail Page

Generator	
L-P	0 W
L-V	240.2 Vac
Frequency	50.01 Hz
Total	0.0 kWh

Generator Power,Voltage and Frequency.
Generator exportation for Total.

Load Detail Page

Load	
Power	26 W
L1-V	120.1 Vac
L1-P	0 W
Today	0.0 kWh

Load Power.
Voltage,Power for each phase.
Load consumption for Day and Total.

7.3 Setting Menu

Setting Menu	
Basic Settings	
Operating Modes	
Grid Settings	
Generator Settings	
Battery Settings	
Advanced Functions	

This is Setting menu detail page.


7.4 Basic Settings



Factory Reset: Reset all parameters of the Inverter.

Lock Out All Changes: Enable this menu for setting parameters that require locking and can not be set up. Before performing a successful factory reset and locking the systems, to keep all changes you need to type in a password to enable the setting. The password for factory settings is 9999.

7.5 Battery Settings



Lithium: Choose Lithium for Battery Mode if lithium battery is used.

Battery Capacity: Enter the size of the battery bank connected to the system.

Use Battery V: When using lead-acid battery, choose Use Battery V if you want to use voltage as the unit of actual battery capacity and do the setup.


Use Battery %: When using lead-acid

battery, choose Use Battery %, if you want to use percentage as the unit of actual battery capacity and do the setup.

Max Charge/Discharge: Set the max charge/discharge rate for the batteries.

No Battery: Tick this item if no battery is connected to the system.

Revive Battery: If lithium battery is used but the inverter and the battery are incompatible in communication, please enable the Revive Battery function to wake up the battery. If the lithium battery is compatible with the inverter in communication, then the inverter is able to wake the lithium battery when PV or grid is connected whether the Revive Battery function is enabled or not.



Recharge (Left) : When there is a blackout and Automatic Start for generator is enabled the generator will automatically start and charge the battery if the actual battery capacity is lower than the Recharge value.

Charge Rate = 40Adc: The maximum generator charging current.

Charge Rate(Left): Current of generator charging the battery.


Gen Charge: Enable this to allow generator to charge the battery

Recharge (Right) : To be developed.

Charge Rate (Right) : Current of grid charging the battery.

Charge Rate = 40Adc: The maximum grid charging current.

Grid Charge: Enable this to allow grid to charge the battery



Lithium Mode: The communication protocol used between the inverter and lithium battery. Please set this according to the Appendix I at the end of user manual.

LBCO: Low Battery Cut Off. The default value is 20%. The minimum value that can be set is 5%. The set value must match LBCO<LBCO alarm<LBCI, otherwise the setting will not be successful. The inverter

will shutoff its AC output if the actual battery capacity is lower than this value. The backup load can still be powered by the grid.

LBCO Alarm: Low Battery Cut Off Alarm, the inverter will send alarm if the actual battery value reaches this value.

The default value is 35%. The minimum value can be set is 10%. The set value must match LBCO<LBCO alarm<LBCI, otherwise the setting will not be successful.

LBCI: Low Battery Cut In. The inverter AC output will resume if actual battery capacity reaches this value. The default value is 50%. The minimum value can be set is 29%. The set value must match LBCO<LBCO alarm<LBCI, otherwise the setting will not be successful.



Float, Absorption, Equalization are three stages of charging the battery.

LBCO 42Vdc: The inverter will shutdown if the voltage below this value.

LBCO Alarm 44Vdc: The inverter will alarm if the voltage below this value.


LBCI 46Vdc: After the battery low voltage alarm, the alarm information above 46V is cleared.

This is for professional installers, you can keep it if you do not know.

Recommended battery settings:

Battery Type	Absorption	Float	Equalization
AGM(or PCC)	14.4V(57.6V)	13.5V(53.6V)	14.4(57.6V)
Gel	14.1V(56.4V)	13.5V(54.0V)	
Wet	14.7V(59.0V)	13.7V(55.0V)	14.7(59.0V)
Lithium	Follow its BMS voltage parameters		

7.6 Operating Modes



On Grid Mode: The inverter will sell any excess power produced by the solar panels back to the grid. If you enables the "time of use" function, the battery energy can also be sold into grid.

The PV energy will be used to power the load and charge the battery and then excess energy will flow to grid.

Power source priority for the load is as follows:



1. Solar Panels.
2. Grid.
3. Battery.

General description:

- a. The inverter will measure all power from the "GRID" terminal as sell power.
- b. External CT sensor not required for this system work mode.

c. Enable "ON Grid Mode" function and set the "Max Sell Power" (KW).

(How to install CT and set CT, please refer to 3.6 and 7.9).



Self-consumption Mode: Hybrid


inverter will only provide power to the backup load connected. The hybrid inverter will neither provide power to the home load nor sell power to grid. The built-in meter will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load and charge the battery.


Enable "PV Sell", it can sell electricity to

the power grid.

General description not select "PV Sell":

- a. The inverter will only cover the loads connected to the "Backup LOAD" terminal.
- b. This work mode will not provide power to the "GRID" terminal.
- c. This system work mode is recommended for off-grid applications.






Zero Export Limit: Hybrid inverter will not only provide power to the backup load connected but also provide to the home load connected. If PV power is insufficient, it will take grid energy as supplement unless TOU or grid peak shaving is set. The hybrid inverter will not sell power to grid. In this mode, a meter is needed. The installation method of the meter please refer to chapter

2.6 Meter Connection, The external meter will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load, charge battery and home load. Enable "PV Sel" it can sell electricity to the power grid. General description not select "PV Sell":

- Power is delivered to the whole home without selling the excess solar back to the grid.
- External CT sensor required for this system work mode. (How to install CT and set CT, please refer to 3.6 and 7.9)
- Enable "Grid Peak-Shaving" and set "Peak-shaving power(KW)" which is used to set the maximum power that the inverter will draw from its grid power.



PV Sell: "PV sell" is for Self-consumption Mode or Zero Export Limit Mode: When this item is selected, the surplus energy can be sold back to grid. PV Power source priority usage is as follows: load consumption and charge battery and feed into grid.


Max Sell Power: Allowed the maximum output power to flow to grid.

PV Priority: PV Power source priority.

Battery First: PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Load First: PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Grid Peak Shaving: when it is selected, grid output power will be limited within the set value. If the load power exceeds the allowed value, it will take PV energy and battery as supplement, If still can't meet the load requirement, grid power will increase to meet the load needs. Under this working condition, only "Load First" can be selected. (This function can only take effect in Zero Export Limit mode). The minimum setting value is 1000W.



Time Of Use: It is used to program when to use grid or generator to charge the battery, and when to discharge the battery to power the load. Only tick "Time Of Use" then the follow items (Grid Charge, Gen Time, Power, Battery) will take effect. Using this mode, the inverter is allowed to discharge the battery to the grid or charge it to the battery within a specific time frame.

General description:

- During the setting hours the system will discharge the batteries to deliver power or charge the batteries from the external AC power. All time intervals are automatically enabled.
- Enable "Time of Use" function and set the Forced discharge time to discharge the batteries to deliver power.

Note: when in ON Grid Mode and click time of use, the battery power can be sold into grid.

Grid Charge: Utilize grid to charge the battery in a time period.

Gen: Utilize diesel generator to charge the battery in a time period.

Time: The time displayed on the inverter, range of 00:00-23:59.

Power: Max discharge power of battery allowed.

Battery(V or SOC %): Battery SOC % or voltage at when the action is to happen. The default setting range is 44 to 54V.

Gen: The generator does not currently support Time Of Use.



For example:

During 09:00-18:00, when battery SOC is lower than 80% it will use grid to charge the battery until battery SOC reaches 80%.

During 18:00-09:00, when battery SOC is higher than 80%, hybrid inverter will discharge the battery until the SOC

reaches 80%.

Battery: The default setting range is 36% to 100%.

End M-D: End Time.

Week setting: The TOU function will only take effect after selecting the week.

Seasons: Enable Button(After selecting this option,Season1,2,3 will only take effect.

Season1,2,3: Automatically select based on the current time period.

Start M-D: Time on.

Q (V): It adjusts the inverter reactive power according to the set grid voltage. This function adjusts inverter output (active and reactive) power when grid voltage changes.

FW: This series inverter is able to adjust inverter output power according to grid frequency.

VW: It adjusts the inverter active power according to the set grid voltage.

7.7 Grid Settings

Grid Mode: Please follow the local grid code and then choose the corresponding grid standard.

Grid Type:Set the Grid Type.

Enter Service Frequency/Voltage: Grid-connected voltage frequency range.

Grid Frequency/Voltage Range: Grid voltage frequency protection range.

Grid Frequency: Set the grid frequency.

Reconnection time: The waiting time period for the inverter to connect the grid again.

PF: This is used to adjust the inverter's reactive power.

HV1: Level 1 overvoltage protection point.

HV2: Level 2 overvoltage protection point.

LV1: Level 1 undervoltage protection point.

LV2: Level 2 undervoltage protection point.

LV3: Level 3 undervoltage protection point.

HF1: Level 1 over frequency protection point.

HF2: Level 2 over frequency protection point.

LF1: Level 1 under frequency protection point.

LF2: Level 2 under frequency protection point.

14.64s: Trip time.

7.8 Generator Settings

correctly.

On Grid Always On: When click "on Grid always on" the smart load will switch on when the grid is present.

Cooldown Time: The amount of time the generator runs (no load) after the shutdown command is issued before the generator is actually shut down.

Maximum Run Time: When automatically started, the cumulative time allowed for continuous operation of the generator within 24 hours. The generator can be operated manually for any length of time.

Smart Load: Allows the generator to terminate the load.

For AC Coupled Input to Gen: connect the grid to the generator input port.

AC Couple On Load Side: connecting the output of on-grid inverter at the load port of the hybrid inverter. In this situation, the hybrid inverter will not able to show the load power

High/Low Voltage Limit:

Generator-connected voltage range.

High/Low Frequency Limit:

Generator-connected frequency range.

Warmup Time: After startup, the amount of time the generator runs (no-load) before the inverter is connected to the generator.

7.9 Advanced Functions

The password for entering this pages is 7777.

Solar Arc Fault ON: This is AFCI function.

Gen Peak-shaving: Enable When the power of the generator exceeds the rated value of it, the inverter will provide the redundant part to ensure that the generator will not overload.

BMS_Err_Stop: Enable "BMS_Err_Stop", if BMS communication is abnormal, the inverter will disconnect its output. After communication is restored, the inverter will return to normal.

Signal ISLAND MODE: when the inverter connects grid, the ATS port will output 240Vac and it is used to cut off Earth-Neutral (load port N line) bond via connect external relay. When the inverter disconnects from the grid, ATS port voltage will be 0 and the Earth-Neutral bond keeps on. More details, please refer to above picture.

Clear Arc Fault: Clear AFCI error messages.

Backup Delay: To be developed.

Gen Peak-shaving: To be developed.

CT Ratio: The inverter support 4 ratios of CT clamp-1500:1, 2000:1, 2500:1 and 3000:1. The CT Ratio of the CTs in the accessory bag is 2000:1.

CT direction: The default CT direction is the arrow on the CT pointing from the grid to the machine.


Parallel: This is the inverter's parallel function interface setting.

Ex_Meter For CT: This is the CT setting for the inverter, please leave it unchecked.

ParallelThreeEn: Three Phase enable.

Modbus SN: To be developed.


Meter Select: Selection of electric meter.



Maximum allowed current at busbar:
Maximum value of busbar protection current.

Fail Safe Current: Can set the fault safety current value.

7.10 Device Info.



Inverter ID: This is the ID of the inverter.

HMI/M1/M2 Ver: This is the software version number of the inverter.

LCD Ver: LCD Version.

Clear Record: Clear error alarm messages.

8 Error Information and Processing

Error codes are divided into Warning codes and fault codes.

Warning codes identify the current status of the inverter(Max), it does not affect the normal running of the inverter.

When a numeric warning appears on the Main Screen, it can usually be cleared through orderly shutdown/re-set or self-corrective action performed by the inverter. Fault codes identify the possible equipment failure. Incorrect setting or configuration of the inverter, all attempts to clear the fault code must be performed by qualified personnel.

Typically, error codes can be cleared. Some of error code as table shows below.

Auditing routine	Error Code	Description	Solutions
About PV	W81	PV Energy Low Warning	1.Check whether the PV voltage is too low. 2.If alarm message still exists, contact manufacturer.
	W83	PV Volt Over Warning	1.Check whether the PV voltage is greater than 525V. 2.If alarm message still exists, contact manufacturer.
	W84	PV Curr Over Warning	If there is an alarm message, please contact the manufacturer.
	W89	PV Over Load	1.Check whether the single-channel PV power exceeds 11 kW. 2.If alarm message still exists, contact manufacturer.
	F33	PV Current Over	1.Check the connection between the PV module and the battery module. 2.Reduce the number of load connections in off-grid mode. 3.If the fault persists, contact the manufacturer.
	F39	Self Check Fault	1.Restart the inverter. 2.If the fault persists, contact the manufacturer.
	F40	PV Voltage Over	1.Check whether the actual PV voltage is consistent with the Main Screen. 2.Check whether the PV string voltage (Voc) is higher than the maximum input voltage of the inverter. If yes, adjust the number of PV modules in series to reduce the PV series voltage. 3.If the fault persists, contact the manufacturer.
About Grid . Generator	F56	PV ISO Fault	1.Check whether the connection between the PV module and the inverter is firm and correct. 2.Check whether the PE cable of the inverter is grounded. 3.If the fault persists, contact the manufacturer.
	W68	Grid Relay Warning	1.Restart the inverter. 2.If alarm message still exists, contact manufacturer.
	W71	Gen Overload warning	1.Check whether the generator power exceeds 10 kW. 2.If alarm message still exists, contact manufacturer.
	F17	Grid Angle Fault	1.check grid type and frequency. 2.Restart the inverter. 3.If the fault persists, contact the manufacturer.
	F26	Grid Type Fault	1.Restart the inverter. 2.If the fault persists, contact the manufacturer.
	F28	Gen Overload Fault	1.Check whether the generator power exceeds 10 kW. 2.If the fault persists, contact the manufacturer.

About inverter	W01	Fan lock warning	1.Check fan wiring after shutdown. 2.If alarm message still exists, contact manufacturer.
	W02	Meter Connect warning	1.Check meter wiring after shutdown. 2.If alarm message still exists, contact manufacturer.
	W03	LCD Connect warning	1.Check LCD wiring after shutdown. 2.If alarm message still exists, contact manufacturer.
	W04	USB Connect warning	1.Check USB wiring after shutdown. 2.If alarm message still exists, contact manufacturer.
	W10	RSD stop press alarm	1.Check if the emergency stop button is pressed. 2.If alarm message still exists, contact manufacturer.
	W11	M3 update alarm	1.Check if the machine is in the process of upgrading. 2.If alarm message still exists, contact manufacturer.
	W12	MDSP update alarm	
	W13	SDSP update alarm	
	W67	Inverter Relay Warning	1.Restart the inverter. 2.If alarm message still exists, contact manufacturer.
	W70	GFCI Warning	1.Please charge for 10 minutes before inverter. 2.If alarm message still exists, contact manufacturer.
	W73	MDSP-METER Connect warning	1.Check meter wiring after shutdown. 2.If alarm message still exists, contact manufacturer.
	W80	CT Warning	1.Please check the wiring of the current transformer. 2.If alarm message still exists, contact manufacturer.
	W85	Mos Temperature Over	If there is an alarm message, please contact the manufacturer.
	W86	Transfer Temperature Over	If there is an alarm message, please contact the manufacturer.
	W88	AFCI Curr Over Warning	1.Shut down and check for poor contact or tearing of PV component wires. 2.If the fault persists, contact the manufacturer.
	W90	Insulation Low	1.After shutdown, check if the panel shell is reliably grounded. 2.If alarm message still exists, contact manufacturer.
	W91	AFCI Communication fail	1.After shutdown, check if the AFCI line inside the machine has fallen off. 2.If the fault still exists, please contact us for help.
	W92	AFCI selftest fail	1.Restart inverter. 2.If the fault persists, contact the manufacturer.
	F18	Inverter Over Curr Fault	1.Check if the load is within the power range. 2.Restart the inverter. 3.If the fault persists, contact the manufacturer.
	F19	MSDSP Connect Fault	1.Restart the inverter. 2.If the fault persists, contact the manufacturer.
	F24	Inverter Voltage Fault	1.Test if the actual output inverter voltage is consistent. 1.Restart the inverter. 2.If the fault persists, contact the manufacturer.
	F25	Relay Fault	1.Restart the inverter.
	F27	GFCI Fault	2.If the fault persists, contact the manufacturer.
	F34	Bus Volt Over	1.Restart the inverter 2-3 times. 2.If the fault persists, contact the manufacturer.
	F35	Bus Volt Unbalance	
	F34	Bus Volt Over	
	F41	Heat Sink High Temperature Failure	1.Check that the inverter is not installed in a place where the sun shines, and ensure that the inverter is installed in a cool and ventilated place.

About Load	F42	Transfer Temperature Over	2.Check whether the working temperature is too high, and make sure that the inverter is installed vertically. 3.Turn off the inverter for 10 minutes, then restart the inverter. 4.If the fault persists, contact the manufacturer.
	F43	AFCI SDSP Connect warning	1.Shut down and check whether the communication line is firmly connected. 2.Restart the inverter. 3.If error message still exists, contact manufacturer.
	F44	AFCI Check warning	1.Restart the inverter.
	F45	BUS Start Error	2.If the fault persists, contact the manufacturer.
	F49	M3MDSP Connect Fault	1.Shut down and check whether the communication line is firmly connected. 2.Restart the inverter. 3.If the fault persists, contact the manufacturer.
	F52	RSD Check Fault	1.Restart the inverter.
	F53	Version Different	2.If the fault persists, contact the manufacturer.
	W65	Output Short Warning	1.Output is short circuit. 2.Shut down and restart to check whether the machine can work normally. 3.If alarm message still exists, contact manufacturer.
	W66	Output Overload Warning	1.Check whether the output is short-circuited. 2.Shut down and restart to check whether the machine can work normally. 3.If alarm message still exists, contact manufacturer.
	F20	DC Weight High	1.Restart the inverter. 2.If the fault persists, contact the manufacturer.
	F21	Output Short	1.Check if the load is short circuited. 2.Restart the inverter. 3.If the fault persists, contact the manufacturer.
	F22	Output Over Load	1.Check if the load is within the power range. 2.Restart the inverter. 3.If the fault persists, contact the manufacturer.
	F23	Output Over Curr	1.Restart the inverter. 2.If the fault persists, contact the manufacturer.
About Battery	W14	BMS update alarm	1.Check if the machine is in the process of upgrading. 2.If alarm message still exists, contact manufacturer.
	W15	BMS alarm	If alarm message still exists, contact manufacturer.
	W16	BMS update parameter alarm	1.Please set the 'Lithium Mode' to 01 in the Battery Settings on the LCD, then proceed with the battery upgrade. 2.If alarm message still exists, contact manufacturer.
	W69	Bat Energy Warning	1.Please charge for 10 minutes before inverter. 2.If alarm message still exists, contact manufacturer.
	W82	Bat Volt Low Warning	1.Check if the battery voltage is too low. 2.If alarm message still exists, contact manufacturer.
	W87	Battery Missing Warning	1.There is no electric voltage at the input end of the machine battery. 2.After confirming that the battery voltage is normal, turn on the machine to check whether it can work normally. 3.If alarm message still exists, contact manufacturer.

	F36	Battery Voltage Over	1.Check whether the actual connected battery voltage is consistent with the display. 2.If the battery voltage is too low, use photovoltaic or commercial power to charge the battery. If the battery voltage is too high, please connect to a battery within the required range. 3.If the fault persists, contact the manufacturer.
	F37	Bat Charge Current Over	1.Check whether the actual battery current is consistent with the display.
	F38	Bat DisCharge Current Over	2.Restart the inverter. 3.If the fault persists, contact the manufacturer.
	F51	M3MDSP Connect Fault	1.Shut down and check whether the communication line is firmly connected. 2.Restart the invert. 3.If the fault persists, contact the manufacturer.
	F57	BMS Fault	1.Restart the inverter.
	F58	Battery Mode Fault	2.If the fault persists, contact the manufacturer.
About Parallel	W05	Parallel Grid different	1.After shutting down the inverter, check if the grid power supply cables are correctly connected. 2.If the warn persists, contact the manufacturer.
	W06	Parallel Phase Error	1.After disconnecting the grid power supply from the inverter, check whether the grid connection phase sequence matches the parallel operation settings on the Main Screen. 2.Restart the inverter. 3.If the warn persists, contact the manufacturer.
	W07	Op Phase Loss Error	1.Check if the parallel operation parameters settings on the inverter's LCD interface are correct. 2.Restart the inverter. 3.If error message still exists, contact manufacturer.
	W08	Parallel version different	If the warn still exists, please contact us for help.
	W09	Capacity different	If the warn still exists, please contact us for help.
	F29	Parallel Setting Fault	1.Check if the master-slave settings in the parallel operation settings on the LCD interface of the inverter are correct . 2.Restart the inverter. 3.If error message still exists, contact manufacturer.
	F30	Parallel M-AC Phase Order	1.After disconnecting the grid power supply connected to the inverter, check whether the grid connection phase sequence matches the parallel operation settings. 2.Restart the inverter. 3.If error message still exists, contact manufacturer.
	F31	Parallel CN-AC Phase Order	1.Restart the inverter. 2.If error message still exists, contact manufacturer.
	F54	Can Fault	1.After shutting down the inverter, check if the parallel communication cables are securely and correctly connected. 2.Restart the inverter. 3.If error message still exists, contact manufacturer.
	F55	Host Loss	1.Restart the inverter. 2.If error message still exists, contact manufacturer.
	F59	Parallel BMS Connect Error	1.Connect the BMS communication cable to the 'Master Phase A' port of the inverter. 2.Restart the inverter. 3.If error message still exists, contact manufacturer.

9 Data Sheet

Model	SPH 10000TL-HU-US(B)
PV Input Data	
Max Recommended PV Power	15000W
DC/AC Ratio	1.5
PV Input Voltage(V)	370V(130V-525V)
MPPT Range(V)	150V-450V
Start-up Voltage(V)	130V
PV Input Current(A)	22A+22A+22A
No. of MPPT Trackers	3
No. of PV strings per MPPT trackers	2/2/2
Battery Data	
Battery Type	Lead-acid or Li-Ion
Nominal Voltage(V)	48V
Battery Voltage Range(V)	40-60V
Max. Charging Current(A)	200A
Max. Discharging Current(A)	200A
output Data (On Grid)	
Rated Voltage	120/240Va.c.(split phase), 208Va.c.
Continuous power output(W)	10000W
Nominal Output Current(A)	41.7A
Max. AC Current(A)	50A
Power Factor	0.8 leading to 0.8 lagging
Output Frequency	60Hz
Grid Type	Split phase
THDI	<3%
Backup Power (Off Grid)	
Rated Voltage	120/240Va.c.(split phase), 208Va.c.
AC Nominal Output Power(W)	10000W
Peak Power(grid off)	1.5 times of rated power, 5s
AC Output Rated Current(A)	41.7A
Output Frequency	60Hz
Switch Time	<10ms
Efficiency	
Max. Efficiency	98.10%
Euro Efficiency	97.60%
MPPT Efficiency	99.90%

Protection	
PV Switch	Yes
BAT reverse protection	Yes
Output over current protection	Yes
AC short-circuit protection	Yes
PV Input Lightning Protection	Yes
Anti-islanding Protection	Yes
PV String Input Reverse Polarity Protection	Yes
Insulation Resistance Monitoring	Yes
Residual Current Monitoring Unit	Yes
AFCI protection	Yes
Surge Protection	DC Type II / AC Type II
Certifications and Standards	
Grid support regulation	IEEE 1547-2003、IEEE 1547-2018、CA Rule 21、 HECO 14H、ISO NE2021、PREPA
Safety	IEC62109-1, IEC62109-2
EMC	EN61000-6-1, EN61000-6-3, FCC Part 15 Class B
General Data	
Operating Temperature Range(°C)	-25~60°C , >45°C Derating
Cooling	Smart cooling
Noise(dB)	<30 dB
Communication with BMS	RS485; CAN
Weight(kg)	42.5
Size(mm)	457.2W*874H*255.6D
Protection Level	IP65
Installation Style	Wall-mounted
Warranty	5 years

10 Appendix I


Approved battery brand from Growatt.

Brand	Model	RS485 or CAN	Inverter Setup
GROWATT	ALP 5.0L-E2-US	CAN	01
	AXE 5.0L-C1	CAN	01
	HOPE 5.5L-A1	RS485	00
SACOLAR	STR 5.5-A1	CAN	01
		RS485	00
Energysys	OGHB 1548-LI	CAN	02
TOPBAND	TB48100F-T110AD	RS485	03
PYLON	Pylontech-US3000C	CAN	04

11 Appendix II

Definition of RJ45 Port Pin for BMS.

NO.	BMS
1	RS485B
2	RS485A
3	/
4	CAN-H
5	CAN-L
6	GND
7	/
8	/



12 Appendix III

CT installation recommendation.

CT model	CT ratio	CT aperture	Property	Recommendation system
100A	2000:1	17mm	Standard configuration	split-phase system
250A	4000:1	37mm	Additional purchase	2 PCS three-phase parallel systems 3 PCS three-phase parallel systems 2-3 PCS split-phase parallel system
500A	7500:1	37mm	Additional purchase	4-6 PCS split-phase parallel systems 6 PCS three-phase parallel systems

13 Appendix IV

Meter installation recommendation

Meter type	Property	Recommendation system
AGF-AE-D/200	Additional purchase	Split-phase system
SDM630MCT	Additional purchase	2-6 PCS three-phase parallel systems 2-6 PCS split-phase parallel systems

14 Appendix V

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in mobile(min20cm) exposure condition.

15 Appendix VI

Certificates

With the appropriate settings, the unit will comply with the requirements specified in the following standards and directives (dated: Aug./2024):

Model	Certificates
SPH 10000TL-HU-US(B)	IEEE1547, CA RULE21, RULE14(HECO Compliant), UL1741, UL1741SA/SB, CSA C22.2, PREPA, UL1699B, UL1741 CRD, FCC Part15 Class B, Sunspec